CARVANA HAS YOU COVERED

Whether you are a first time buyer, a repair wizard, or on a strict budget, we've got you covered.

10,000+ In-network Locations

Rental Coverage

24/7 Roadside Assistance

Cancel Anytime

All plans include budget-friendly deductibles* at in-network repair locations. Cosmetic claims are not subject to any deductible.

Deductible options available at check-out. See your CarvanaCare contract for details and limitations.

Affordable options for everyone

Cosmetic Coverage

CarvanaCare Cosmetic covers paintless dent repairs, tire and wheel repairs, plus oil changes and tire rotations for the first year.

Basic Mechanical Coverage

CarvanaCare Essential is our basic level of protection, covering the components that move the vehicle such as the engine, transmission, and drivetrain.

Comprehensive Coverage

CarvanaCare Plus is our next level up, designed for those who prefer comprehensive coverage.This includes everything in our Essential plan and also includes steering, heating, A/C, exhaust, and much more.

Premium Coverage

CarvanaCare Premier is our highest level of coverage, providing mechanical and cosmetic repairs. This plan includes everything in our Essential and Plus plans and also includes **3 oil changes and tire rotations for 1 year,** minor cosmetic repairs, and tire/wheel damage.

Components covered by CarvanaCare

Premier
Premium coverage (includes Cosmetic, Essential and Plus)

Cosmetic
Cosmetic + Maintenance Coverage

Essential
Basic Mechanical Coverage

Plus
Comprehensive coverage (includes Essential)

Tire, Wheel & Dent

- Dent and ding protection
- Tire repair due to damage from road hazard
- Tire replacement due to damage from road hazard
- Wheel repair due to damage from road hazard
- Wheel replacement due to damage from road hazard
- Cosmetic wheel repair

Complimentary Maintenance

- Change engine oil
- Change engine oil filter
- Lubricate front suspension
- Lubricate steering linkage
- Lubricate ball joints
- Multipoint inspection
- Rotate tires

Transmission/ Transfer Case

- Accumulator Pistons
- Accumulator Rings
- Accumulator Seal Bands
- Bearings
- Bell Housing
- Bushings
- Case
- Chains
- Check Balls
- Cooler
- Counter Shafts
- Detent Cable
- Drive Link
- Drive Plate
- Drums
- Flex Plate
- Front Bands
- Gears
- Governor
- Governor Support
- Impeller Hub
- Input Shaft
- Input Turbine
- Intermediate Bands
- Kickdown Bands
- Kickdown Servo
- Main Shaft
- Manual Shaft
- Modulator Valve
- Multifunction Valves
- Oil Pan
- Oil Pump
- Oil Pump Cover
- Output Gears
- Output Shaft
- Output Shaft Bearings
- Parking Lock Sprag
- Parking Pawl
- Pistons
- Planetary Gear Carrier
- Planetary Gears
- Reaction Gear Set
- Rear Bands
- Reverse Bands
- Reverse Servo
- Ring Gears
- Roll Pins
- Roller Clutches
- Servo Rings
- Shift Forks
- Shift Valves
- Side Cover
- Snap Rings
- Speedometer Drive Gear
- Speedometer Driven Gear
- Sprags
- Springs
- Sprocket Supports
- Sprockets
- Stator
- Stator Shaft
- Sun Gears
- Synchronizer Hub
- Synchronizer Rings
- Synchros
- Thrust Washers
- Throttle Valve
- Torque Converter
- Transaxle Case
- Transmission Mounts
- Turbine
- Vacuum Modulator
- Valve Body
- Valve Solenoids

Engine

- Balance/Silent Shafts
- Balance Shaft Chains
- Balance Shaft Sprockets
- Cam Bearings
- Cam Bolts
- Cam Cover
- Cam Follower
- Camshafts
- Camshaft Sprockets
- Compression Rings
- Connecting Rods
- Crankshaft
- Crankshaft Pulley
- Crankshaft Sprockets
- Cylinder Block
- Cylinder Heads
- Engine Mounts
- Exhaust Manifolds
- Exhaust Valves
- Harmonic Balancer
- Intake Manifold
- Intake Valves
- Intermediate Shaft Lifters
- Main Bearing Caps
- Main Bearings
- Oil Pan
- Oil Pressure Relief Spring
- Oil Pump
- Oil Pump Gears
- Oil Pump Pickup
- Oil Rings
- Piston Rings
- Pistons
- Pushrods
- Rocker Arm Studs
- Rocker Arms
- Rod Bearings
- Supercharger
- Tappets
- Thrust Pins
- Timing Belt
- Timing Belt Tensioner
- Timing Gears/Sprockets
- Turbocharger
- Valve Covers
- Valve Keepers
- Valve Lifters
- Valve Seats
- Valve Springs
- Valve Stem Guides
- Valve Stem Seals
- Wrist Pins

Front/Rear Wheel Drive

- Axles
- Axle Shaft
- CV Joints
- Differential Carrier
- Differential Housing
- Drive Shaft
- Half Shafts
- Pinion Gear
- Positraction Clutches
- Ring Gears
- Side Bearings
- Side Gears
- Slip Joints
- Spider Gears
- Universal Joints
- Wheel Bearings
- Yokes

Electric/Hybrid

- Drive Motor/Generator
- High Voltage Battery
- Inverter
- On-Board Charger

Transmission/Transfer Case

- Clutch Master Cylinder
- Clutch Pilot Bearing
- Clutch Slave Cylinder
- Clutch Throw Out Bearing
- Electronic Shift Control Unit
- Flywheel
- Pressure Plate
- Range Sensor
- Transmission Control Module (TCM)
- Transmission Wiring Harness
- Seals and Gaskets for Covered Components

Engine

- Engine Control Module (ECM)
- Engine Oil Cooler
- Engine Wiring Harness
- Oil Filter Adaptor Housing
- Variable Valve Timing Actuator
- Variable Valve Timing Solenoid
- Seals and Gaskets for Covered Components

Front/Rear Wheel Drive

- Center Support Bearing
- CV Boots
- Differential Covers
- Locking Hubs
- Wheel/Hub Bearings
- Seals and Gaskets for Covered Components

Fuel and Emissions

- Evap Canister
- Fuel Injector
- Fuel Injection Pump
- Fuel Level Sensor
- Fuel Pump
- Fuel Pressure Regulator
- Fuel Rail Pressure Sensor
- Fuel Tank Sending Unit
- Intake Air Temperature Sensor
- Leak Detection Pump
- MAP Sensor
- Mass Air flow Sensor
- Purge Valve/Solenoid
- Throttle Body
- Throttle Position Sensor
- Solenoid Vent Valve
- Seals and Gaskets for Covered Components

Heating and A/C

- A/C Compressor
- Accumulator
- Blower Motor
- Blower Motor Resistor
- Blower Motor Switch
- Compressor Clutch
- Consenser
- Consenser Fan Motor
- Coolant Heater Controller
- Evaporator Core
- Expansion Valve
- Heater Core
- HVAC Actuators
- HVAC Control Unit
- HVAC Control Head
- Hybrid/Electric Coolant Heater
- Interior/Exterior Temperature Sensor
- Orifice Tube
- Receiver/Dryer
- Seals and Gaskets for Covered Components

Steering

- Electric Steering Motor
- EVO Sensor
- Power Steering Pump
- Rack and Pinion Assembly
- Steering Angle Sensor
- Steering Gear
- Steering Knuckles
- Seals and Gaskets for Covered Components

Suspension

- Ball Joints
- Control Arms
- Control Arm Bushings
- Control Arm Shafts
- Electric Level Control Actuator
- Electronic Level Control Compressor
- Electronic Level Control Height Sensor
- Electronic Level Control Module
- Spindles
- Stabilizer Bar
- Stabilizer Bar Bushings
- Torsion Bar
- Torsion Bar Bushings
- Torsion Bar Mounts
- Track Bar
- Track Bar Bushings
- Wheel Bearings
- Yaw Rate Sensor
- Seals and Gaskets for Covered Components

Brake System

- ABS Accumulator
- ABS Control Module
- ABS Hydraulic Pump/Motor Assembly
- ABS Wheel Speed Sensors
- Brake Booster
- Caliper(s)
- Master Cylinder
- Vacuum Pump
- Wheel Cylinder
- Seals and Gaskets for Covered Components

Cooling System

- Engine Cooling Fan Clutch
- Engine Coolant Level Sensor
- Engine Coolant Temperature Sensor
- Thermostat
- Turbo Charger Intercooler
- Water Pump
- Radiator
- Cooling Fan Motor
- Seals and Gaskets for Covered Components

Electrical

- HVAC Control Module
- Accelerator Pedal Position Sensor
- Air Bag Module
- Air Bag Sensor
- Alternator
- Body Control Module (BCM)
- Camshaft Sensor
- Clock Spring
- Convertible Top Motor
- Convertible Top Switch
- Crankshaft Sensor
- Dash Light Dimmer Switch
- Hazard Warning Switch
- Instrument Cluster
- Ignition Coil/Coil Pack
- Ignition Module
- Ignition Lock Cylinder
- Impact Sensor
- Keyless Entry Receiver
- Keyless Entry Remote
- Knock Sensor
- Oil Level Sensor
- Oil Pressure Sending Unit
- Oxygen Sensor
- Power Door Lock Actuators
- Power Hatch Lift Motor
- Power Mirror Motor
- Power Seat Motors
- Power Window Motors and Regulators
- Powertrain Control Module (PCM)
- Rear Hatch Motor
- Rear View Camera
- Sliding Door Motor
- Starter Motor
- Tire Pressure Sensors
- Window Washer Pump
- Window Wiper Motor
- Wiring Harness

Electric/Hybrid

- AC Charger
- Battery Current Sensor
- Battery Pack
- Battery Temp Sensor
- DC-DC Converter
- Inverter
- Vehicle Control Unit (VCU)

Important, please read:

Every effort has been made to provide a complete list of covered components. Exclusions and limitations apply, refer to your contract terms and conditions for details and limitations.

In Florida, CarvanaCare is provided by SilverRock Automotive of Florida, Inc., P.O. Box 29087, Phoenix, AZ 85038-9087, Florida License #30847

Included in every plan
ROADSIDE ASSISTANCE

Towing | Jump Start | Flat Tire Assistance | Locksmith Assistance | Emergency Gas/Fluids

CARVANA